






















Wythenshawe Hall Refurbishment Works - Proposed Finishes Schedule Rev.01

Room Description / Area	Floors	Flooring Sample	Walls	Colour Sample	Ceilings	Colour Sample	Woodwork	Colour Sample	Metalwork	Colour Sample
Ground Floor Areas										
Tenant Hall / Suite A0/36	Existing carpet finish - Section to be repaired to match existing.	N/A	Painted Brick Finish - Prepare surfaces and apply 2No. coats of Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to be Silent White Deep 331		No works to be carried out.		Woodwork to Windows – To carry out all necessary preparation work and to apply 1No. oil undercoat and 1No. coat of Traditional Oil Gloss, all as manufactured by Little Greene Paint & Paper to all previously painted timberwork. Colour to be Rectory White		N/A	
Bar Area A0/35	Existing carpet finish - No works to be carried out.	N/A	Plaster Wall Finish - Prepare surfaces and apply 2No. coats of Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to be Silent White Deep 331		Plaster Ceiling Finish - Prepare surfaces and apply 2No. coats of Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to be Down 242	 Down. 242.	Woodwork to Skirtings – To carry out all necessary preparation work and to apply 1No. oil undercoat and 1No. coat of Traditional Oil Gloss, all as manufactured by Little Greene Paint & Paper to all previously painted timberwork. Colour to be Chocolate (124)	 Chocolate Colour™ 124.	N/A	
Circulation Area A0/35a	Existing carpet finish - Section to be repaired to match existing.	N/A	Plaster Wall Finish - Prepare surfaces and apply 2No. coats of Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to be Down 242	 Down. 242.	Continuous Skylight Support Brackets - To carry out all necessary preparation work and to apply 1No. oil undercoat and 1No. coat of Traditional Oil Gloss, all as manufactured by Little Greene Paint & Paper to all previously painted timberwork. Colour to be Rectory White		Woodwork to Doors, Frames & Skirtings – To carry out all necessary preparation work and to apply 1No. oil undercoat and 1No. coat of Traditional Oil Gloss, all as manufactured by Little Greene Paint & Paper to all previously painted timberwork. Colour to be Chocolate (124)	 Chocolate Colour™ 124.	Wall mounter electric Heater - to apply 1No. oil undercoat and 1No. coat of Traditional Oil Gloss, all as manufactured by Little Greene Paint & Paper to all previously painted timberwork. Colour to be Chocolate (124)	 Chocolate Colour™ 124.
Circulation Area A0/30	Existing Wood Block Flooring and Floor Boards - Allow for applying 2No. coats of Fiddes Hard Wax oil Satin Finish, strictly in accordance with the manufacturer’s instructions. Supplier – Fiddes & Son, Florence Works, Brindley Road, Cardiff CF11 8TX.	N/A	Plaster Wall Finish - Prepare surfaces and apply 2No. coats of Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to be Down 242	 Down. 242.	Plaster Ceiling Finish - Prepare surfaces and apply 2No. coats of Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to be Down 242	 Down. 242.	Woodwork to Doors, Frames & Skirtings – To carry out all necessary preparation work and to apply 1No. oil undercoat and 1No. coat of Traditional Oil Gloss, all as manufactured by Little Greene Paint & Paper to all previously painted timberwork. Colour to be Chocolate (124)	 Chocolate Colour™ 124.	N/A	

Room Description / Area	Floors	Flooring Sample	Walls	Colour Sample	Ceilings	Colour Sample	Woodwork	Colour Sample	Metalwork	Colour Sample
Female W.C. A0/31	Existing Wood Block Flooring - Allow for applying 2No. coats of Fiddes Hard Wax oil Satin Finish, strictly in accordance with the manufacturer’s instructions. Supplier – Fiddes & Son, Florence Works, Brindley Road, Cardiff CF11 8TX.	N/A	Plaster Wall Finish - Prepare surfaces and apply 2No. coats of Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to be Down 242	 Down. 242.	Timber boarded ceiling - following minor repairs to infill holes in ceiling boards, to touch up repairs with Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to match existing.		Previously Painted Woodwork to Doors, Frames, Windows & Skirtings – To carry out all necessary preparation work and to apply 1No. oil undercoat and 1No. coat of Traditional Oil Gloss, all as manufactured by Little Greene Paint & Paper to all previously painted timberwork. Colour to be Chocolate (124) . Window frames to be Rectory White .		N/A	
Male W.C. A0/33	Existing Sheet Vinyl - Replace damaged section of sheet vinyl with new Surestep Original safety vinyl flooring 2.00 mm thick, colour to match existing. All as manufactured by Forbo Flooring UK Ltd.	N/A	Plaster Wall Finish - Prepare surfaces and apply 2No. coats of Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to be Down 242	 Down. 242.	Plaster Ceiling Finish - Prepare surfaces and apply 2No. coats of Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to be Down 242	 Down. 242.	Previously Painted Woodwork to Doors, Frames & Skirtings – To carry out all necessary preparation work and to apply 1No. oil undercoat and 1No. coat of Traditional Oil Gloss, all as manufactured by Little Greene Paint & Paper to all previously painted timberwork. Colour to be Chocolate (124)	 Chocolate Colour™ 124.	N/A	
First Floor Areas										
Office Area A1/12	Existing Timber Floor Boards - Allow for applying 2No. coats of Fiddes Hard Wax oil Satin Finish, strictly in accordance with the manufacturer’s instructions. Supplier – Fiddes & Son, Florence Works, Brindley Road, Cardiff CF11 8TX.	N/A	Plaster Wall Finish - Prepare surfaces and apply 2No. coats of Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to be Boringdon Greem 295		Plaster Ceiling Finish - Prepare surfaces and apply 2No. coats of Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to be Down 242	 Down. 242.	Woodwork to Doors, Frames, Windows & Skirtings – To carry out all necessary preparation work and to apply 1No. oil undercoat and 1No. coat of Traditional Oil Gloss, all as manufactured by Little Greene Paint & Paper to all previously painted timberwork. Colour to be Rectory White .		Metalwork / Radiators – To carry out all necessary preparation work and to apply 1No. oil undercoat and 1No. coat of Traditional Oil Gloss, all as manufactured by Little Greene Paint & Paper to all previously painted timberwork. Colour to be Rectory White .	
Break Out Area A1/18	Existing Timber Floor Boards - Allow for applying 2No. coats of Fiddes Hard Wax oil Satin Finish, strictly in accordance with the manufacturer’s instructions. Supplier – Fiddes & Son, Florence Works, Brindley Road, Cardiff CF11 8TX.	N/A	Plaster Wall Finish - Prepare surfaces and apply 2No. coats of Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to be Down 242	 Down. 242.	Plaster Ceiling Finish - Prepare surfaces and apply 2No. coats of Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to be Down 242	 Down. 242.	Woodwork to Doors, Frames, Windows & Skirtings – To carry out all necessary preparation work and to apply 1No. oil undercoat and 1No. coat of Traditional Oil Gloss, all as manufactured by Little Greene Paint & Paper to all previously painted timberwork. Colour to be Rectory White .		Metalwork / Radiator – To carry out all necessary preparation work and to apply 1No. oil undercoat and 1No. coat of Traditional Oil Gloss, all as manufactured by Little Greene Paint & Paper to all previously painted timberwork. Colour to be Rectory White .	

Room Description / Area	Floors	Flooring Sample	Walls	Colour Sample	Ceilings	Colour Sample	Woodwork	Colour Sample	Metalwork	Colour Sample
Break Out Area A1/18	Existing Treads to Steps - Existing covering to be removed & replaced with Forbo Marmoleum Solid - Linoluem Sheet Flooring.	 Colour samples on site for review of Planner / Conservation Officer.								
Kitchen Area A1/17	Existing Timber Floor Boards - Allow for applying 2No. coats of Fiddes Hard Wax oil Satin Finish, strictly in accordance with the manufacturer's instructions. Supplier – Fiddes & Son, Florence Works, Brindley Road, Cardiff CF11 8TX.	N/A	Plaster Wall Finish - Prepare surfaces and apply 2No. coats of Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to be Down 242	 Down. 242.	Plaster Ceiling Finish - Prepare surfaces and apply 2No. coats of Absolute Matt Emulsion as manufactured by Little Greene Paint and Paper. Colour to be Down 242	 Down. 242.	Woodwork to Doors, Frames & Skirtings – To carry out all necessary preparation work and to apply 1No. oil undercoat and 1No. coat of Traditional Oil Gloss, all as manufactured by Little Greene Paint & Paper to all previously painted timberwork. Colour to be Chocolate (124)	 Chocolate Colour™ 124.	N/A	
W.C. A1/03	Existing Timber Floor Boards - Allow for applying 2No. coats of Fiddes Hard Wax oil Satin Finish, strictly in accordance with the manufacturer's instructions. Supplier – Fiddes & Son, Florence Works, Brindley Road, Cardiff CF11 8TX.	N/A	No works to be carried out.		No works to be carried out.		No works to be carried out.		N/A	
W.C. A1/04	Existing Timber Floor Boards - Allow for applying 2No. coats of Fiddes Hard Wax oil Satin Finish, strictly in accordance with the manufacturer's instructions. Supplier – Fiddes & Son, Florence Works, Brindley Road, Cardiff CF11 8TX.	N/A	No works to be carried out.		No works to be carried out.		No works to be carried out.		N/A	