

Photograph of areas where pipework has been previously removed in the area of the staircase



Photograph of asbestos lagged pipework that will need removing

Sequence of works:

Ceilings to be removed to all bays as indicated on Sheppard Robson plans. These will be removed using small hand tools to the ceilings fixed directly to the timber battens above. Areas where the no fines concrete (a form of lightweight concrete is generally a crushed rock or gravel of 20 mm single size aggregate coated in a cement slurry with no fine aggregate addition) and pipework are, will be removed using a small breaker, the pipework will also be taken out using this method. Care will be taken when carrying out such works as not to damage the Parquet flooring below. To assist with this everything will be taken down in small sections to be bagged and disposed of as asbestos containing material.

Dantzic - Methodology for removal ceilings

Russells Construction