



Slate roof showing
30mm clearance



Step 1: Fix foam to bracket drop.



Step 3: SolarFlash can be trimmed or nailed through. If nailing through, ensure relevant line for slate size centres on the batten. Apply pressure to hold SolarFlash solid when nailing through.



Step 2: As a guide, slate sizes are marked on the SolarFlash.



Step 4: Cut slates around the hood of the SolarFlash as per Page 4.

The top of the cut
SolarFlash should sit
in the centre of the
batten.

Note:
Do not scale drawing. All dimensions and levels to be checked on site and any discrepancies to be reported immediately before the commencement of work. Drawing to be read in conjunction with all relevant drawings and specifications.



PROJECT NAME & LOCATION
Manchester Marriott Victoria &
Albert Hotel, Water St, Manchester
M3 4JQ

DRAWING TITLE:
Typical SolarFlash (Refit)
Installation

PROJECT NO. AN53	DWG NO. 009	REV.
DRAWN. LB	CHECK. GW	SCALE. 1 : 25 @ A3

UNIT 5 CUNNINGHAM COURT
LIONS DRIVE
SHADSWORTH BUSINESS PARK
BLACKBURN
BB1 2QX
T: +44 (0) 1254 774943
E: INFO@ALDROCK.CO.UK

STATUS Planning	DATE 21/11/23
--------------------	------------------

Typical SolarFlash (Refit) Installation

