

Princess Street courtyard Roof slope CBR01 Proposed roof access hatch locations

100 x 50 trimmer screwed to rafters with 2 No 5mm diameter x 125mm long stainless steel screws

Cut rafter fixed to trimmers with 2 No 5mm diameter x 125mm long stainless steel screws

Bottom of opening
to be aligned with
datum - Datum =
bottom of offset to
stone in dormer
cheek

600mm high x
450mm wide
opening

New 100 x 50 full length rafter

New 100 x 50 full length rafter

Datum

100 x 50 trimmer
screwed to rafters
with 2 No 5mm
diameter x 125mm
long stainless steel
screws

Revision: -
First issue
Date: 22 May 2024

Page 1 of 2
North side of dormer

Adjust bricks
(remove or cut off
ends) bif necessary
to fit new rafters ~

OTH-PUR-TH-RF-SKE-A-3643

**Princess Street courtyard
Roof slope CBR01
Proposed roof access hatch
locations**

100 x 50 trimmer
screwed to rafters with
2 No 5mm diameter x
125mm long stainless
steel screws

Cut rafter fixed to
trimmers with 2 No
5mm diameter x
125mm long stainless
steel screws

New 100 x 50 full
length rafter

Bottom of opening
to be aligned with
datum - Datum =
bottom of offset to
stone in dormer
cheek

600mm high x
450mm wide
opening

New 100 x 50 full
length rafter

Datum

100 x 50 trimmer
screwed to rafters
with 2 No 5mm
diameter x 125mm
long stainless steel
screws

Revision: -
First issue
Date: 22 May 2024

**Page 2 of 2
South side of dormer**

OTH-PUR-TH-RF-SKE-A-3643