

Maintenance Schedule

Rainwater Harvesting	Clean the filter unit in the tank and ensure the pump is operating correctly by testing it. Ensure water mains top up or backup system is working by simulating the float switch movement. Check pipework and fittings are tight and the water is clean.	Quarterly for the first year, annually thereafter
Repair/Reinstate	Remove and reconstruct any components of the storm water system when identified during routine maintenance	When required

Any defects (broken/misaligned pipes, root infestation, damage to the attenuation tank, missing parts, etc.) that are identified during inspections/maintenance should be reported back to the property/site owner so that remedial actions can be undertaken promptly to repair these defects.