




- 01 Residents will transfer the waste from their apartment entrances to the refuse store which is located adjacent the development entrances.
- 02 Secure refuse store located at back of the pavement
- 03 Building management will be responsible for ensuring the large doors are open and clear of obstructions on collections. From this point the bins can be collected and loaded into the refuse vehicle.

general refuse

	660L continental trade
	140L wheeled container
	800L total

paper/card recycling

	660L continental trade
	140L wheeled container
	800L total

mixed recycling

	660L continental trade
	140L wheeled container
	800L total

food waste

	140L wheeled container
	140L total

