



Alan Wood & Partners

08<sup>th</sup> May 2026

# Drainage Operation & Maintenance

OMYOP Depot, MCC – Maulddeth Road, Manchester M20 3FG

Project Number: 52753

Doc. Reference: 52753-AWP-ZZ-XX-RP-C-3001

Engineer /  
Manage /  
Deliver /

[www.alanwood.co.uk](http://www.alanwood.co.uk)

## 1.0 Introduction

A new building is proposed to the existing site at OMYOP Depot. This includes a new building and car park area.

Premier Modular Limited commissioned Alan Wood and Partners to undertake the drainage design for the scheme. this technical note stipulates the operation and maintenance requirements and responsibilities for the SuDS elements of the proposed drainage systems

## 2.0 Proposed Drainage Components

The proposed drainage design consists of silt traps, trapped gullies, traditional manholes and pipes, Orifice flow control device, and surface water attenuation storage tank consisting of cellular crates.

The drainage design is shown on Alan Wood and partners drawings; reference 52753-AWP-ZZ-XX-D-C-3000 Drainage layout, along with the associated detail drawings.

## 3.0 Operation and Maintenance

Operation and maintenance requirements of the drainage components, as listed above, should be undertaken in accordance with Chapter 32 of the CIRIA C753 SuDS Manual, along with the relevant tables as included below and any relevant manufacturers recommendations. See also: BS 8582:2013 Code of Practice for Surface Water Management for Developer Sites Section 11, and Susdrain Fact Sheet on SuDS Maintenance and Adoption Options (England) dated September 2015

The responsibility for the operations and maintenance of the drainage SuDS will lie with the Scout Trust and will not be adopted by a public body / statutory undertaker. An initial pre-handover inspection should be undertaken once construction is completed to ensure that this have been constructed as designed.

The staff undertaking the maintenance should have appropriate experience of SuDS and drainage maintenance and should be capable of keeping sufficient detailed records of any inspections. An example of a checklist for SuDS maintenance can be found within Appendix B of the CIRIA C753 SuDS manual V2. If staff do not have appropriate experience, then specific inspection visits may be necessary. During the first year of operation f SuDS, inspections should usually be carried out at least monthly (and after significant storm events)

## 4.0 Maintenance Schedules

Operation and maintenance requirements for the silt traps and trapped gullies is set out in Table 1 below.

**Operation and Maintenance Requirements for Silt Traps/Trapped Gullies (Based on CIRIA C753 Table 14.2)**

| Maintenance schedule                                                                                                                                                                                             | Required action                                                                   | Typical frequency                                                                         |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|
| Routine maintenance                                                                                                                                                                                              | Remove litter and debris and inspect for sediment, oil and grease accumulation    | 6 monthly                                                                                 |
|                                                                                                                                                                                                                  | Change the filter media                                                           | As recommended by manufacturer                                                            |
|                                                                                                                                                                                                                  | Remove sediment, oil, grease and floatables                                       | As necessary – indicated by system inspections or immediately following significant spill |
| Remedial actions                                                                                                                                                                                                 | Replace malfunctioning parts or structures                                        | As required                                                                               |
| Monitoring                                                                                                                                                                                                       | Inspect for evidence of poor operation                                            | 6 monthly                                                                                 |
|                                                                                                                                                                                                                  | Inspect filter media and establish appropriate replacement frequencies            | 6 monthly                                                                                 |
|                                                                                                                                                                                                                  | Inspect sediment accumulation rates and establish appropriate removal frequencies | Monthly during first half year of operation, then every 6 months                          |
| *During the first year of operation, inspections should be carried out at least monthly (and after significant storm events) to ensure that the system is functioning as designed and that no damage is evident. |                                                                                   |                                                                                           |

Operation and maintenance requirements for the attenuation storage tank is set out in Table 2 below.

**Operation and Maintenance Requirements for Attenuation Storage Tank (Based on CIRIA C753 Table 21.3)**

| Maintenance schedule                                                                                                                                                                                             | Required action                                                                                                            | Typical frequency                   |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|-------------------------------------|
| Regular maintenance                                                                                                                                                                                              | Inspect and identify any areas that are not operating correctly. If required, take remedial action.                        | Monthly for 3 months, then annually |
|                                                                                                                                                                                                                  | Remove debris from the catchment surface (where it may cause risks to performance)                                         | Monthly                             |
|                                                                                                                                                                                                                  | Remove sediment from pre-treatment structures.                                                                             | Annually, or as required.           |
| Remedial actions                                                                                                                                                                                                 | Repair/rehabilitate inlets, outlet, overflows and vents                                                                    | As required                         |
| Monitoring                                                                                                                                                                                                       | Inspect/check all inlets, outlets, vents and overflows to ensure that they are in good condition and operating as designed | Annually*                           |
|                                                                                                                                                                                                                  | Survey inside of tank for sediment build-up and remove if necessary                                                        | Every 5 years or as required*       |
| *During the first year of operation, inspections should be carried out at least monthly (and after significant storm events) to ensure that the system is functioning as designed and that no damage is evident. |                                                                                                                            |                                     |

Operation and maintenance requirements for the attenuation lagoon are set out in Table 3 below.

**Operation and Maintenance Requirements for pervious pavements (Based on CIRIA C753 Table 20.15)**

| Maintenance schedule                                                                                                                                                                                             | Required action                                                                                                                                                                      | Typical frequency                                                                                                                                                                                                                                                                                                            |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Regular maintenance                                                                                                                                                                                              | Brushing and vacuuming (standard cosmetic sweep over whole surface)                                                                                                                  | Once a year, after autumn leaf fall, or reduced frequency as required, based on site-specific observations of clogging or manufacturer's recommendations – pay particular attention to areas where water runs onto pervious surface from adjacent impermeable areas as this area is most likely to collect the most sediment |
| Occasional maintenance                                                                                                                                                                                           | Stabilise and mow contributing and adjacent areas                                                                                                                                    | As required                                                                                                                                                                                                                                                                                                                  |
|                                                                                                                                                                                                                  | Removal of weeds or management using glyphosate applied directly into the weeds by an applicator rather than spraying                                                                | As required – once per year on less frequently used pavements                                                                                                                                                                                                                                                                |
| Remedial actions                                                                                                                                                                                                 | Remediate any landscaping which, through vegetation maintenance or soil slip, has been raised to within 50 mm of the level of the paving                                             | As required                                                                                                                                                                                                                                                                                                                  |
|                                                                                                                                                                                                                  | Remedial work to any depressions, rutting and cracked or broken blocks considered detrimental to the structural performance or a hazard to users, and replace lost jointing material | As required                                                                                                                                                                                                                                                                                                                  |
|                                                                                                                                                                                                                  | Rehabilitation of surface and upper substructure by remedial sweeping                                                                                                                | Every 10 to 15 years or as required (if infiltration performance is reduced due to significant clogging)                                                                                                                                                                                                                     |
| Monitoring                                                                                                                                                                                                       | Initial inspection                                                                                                                                                                   | Monthly for three months after installation                                                                                                                                                                                                                                                                                  |
|                                                                                                                                                                                                                  | Inspect for evidence of poor operation and/or weed growth – if required, take remedial action                                                                                        | Three-monthly, 48h after large storms in first six months                                                                                                                                                                                                                                                                    |
|                                                                                                                                                                                                                  | Inspect silt accumulation rates and establish appropriate brushing frequencies                                                                                                       | Annually                                                                                                                                                                                                                                                                                                                     |
|                                                                                                                                                                                                                  | Monitor inspection chambers                                                                                                                                                          | Annually                                                                                                                                                                                                                                                                                                                     |
| *During the first year of operation, inspections should be carried out at least monthly (and after significant storm events) to ensure that the system is functioning as designed and that no damage is evident. |                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                                                              |

Should a vortex flow control valve be required, then this should be maintained as set out in Table 4 below

**Operation and Maintenance Requirements for Vortex Flow Control Device (Based on Manufacturer's recommendations)**

| Maintenance schedule | Required action                                                                   | Typical frequency                                                                         |
|----------------------|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|
| Routine maintenance  | Remove litter and debris and inspect for sediment, oil and grease accumulation    | 6 monthly                                                                                 |
|                      | Remove sediment, oil, grease and floatables                                       | As necessary – indicated by system inspections or immediately following significant spill |
| Remedial actions     | Replace malfunctioning parts or structures                                        | As required                                                                               |
| Monitoring           | Inspect for evidence of poor operation                                            | Monthly during the first three months, then every 6 months                                |
|                      | Inspect sediment accumulation rates and establish appropriate removal frequencies | Monthly during first half year of operation, then every 6 months                          |

The orifice outlet should be regularly maintained as set out in Table 5 below.

**Operation and Maintenance Requirements for Orifice Flow Control**

| Maintenance schedule | Required action                                                                   | Typical frequency                                                                         |
|----------------------|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|
| Routine maintenance  | Remove litter and debris and inspect for sediment, oil and grease accumulation    | 6 monthly                                                                                 |
|                      | Remove sediment, oil, grease and floatables                                       | As necessary – indicated by system inspections or immediately following significant spill |
| Remedial actions     | Replace malfunctioning parts or structures                                        | As required                                                                               |
| Monitoring           | Inspect for evidence of poor operation                                            | Monthly during the first three months, then every 6 months                                |
|                      | Inspect sediment accumulation rates and establish appropriate removal frequencies | Monthly during first half year of operation, then every 6 months                          |

The operations and maintenance for the geo-cellular crates should be regularly maintained as set out in Table 6 below.

#### Operation and Maintenance Requirements for Geo-cellular/modular Systems

| Maintenance Schedule | Required Action                                                                                                                                                                    | Recommended Frequency                   |
|----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------|
| Regular Maintenance  | Inspect and identify areas that are not operating correctly. If required, take remedial action.                                                                                    | Monthly for 3 months, then six monthly. |
|                      | Debris removal from catchment surface (where may cause risks to performance).                                                                                                      | Monthly.                                |
|                      | Where rainfall infiltrates to blocks from above, check surface of filter for blockage by silt, algae or other matter. Remove and replace surface infiltration medium as necessary. | Monthly (and after large storms).       |
|                      | Remove sediment from pre-treatment structures.                                                                                                                                     | Annually, or as required.               |
| Remedial Actions     | Repair-rehabilitation of inlets, outlet, overflows and vents.                                                                                                                      | As required.                            |
| Monitoring           | Inspect/check all inlets, outlet, vents and overflows to ensure that they are in good condition and operating as designed.                                                         | Annually and after large storms.        |

## Services

To support and compliment our core services Alan Wood & Partners have invested in and developed a range of additional services.

### Civil Engineering

Drainage Design  
Earthworks Modelling /  
Cut and Fill Assessments  
External Works and  
Hardstanding Design  
Flood Defence Assessment and Design  
Flood Risk Assessments (FRAs)  
Highways Design  
Retaining Wall and Foundation Design  
Sustainable Drainage Solutions (SuDS)  
Traffic and Transport Assessment  
Utilities Design  
Watercourse Modelling

### Structural Engineering

Blast Design  
Bridge Assessment and Design  
Demolition Assessments and Advice  
Parametric Modelling  
Reinforced Concrete Design  
Retaining Wall and Foundation Design  
Structural Assessments  
Structural Masonry Design  
Structural Steelwork Design  
Structural Timber Design  
Temporary Works Design

### Building Consultancy

Architectural Design  
Asset Management  
and Lifecycle Surveys  
BREEAM  
Backlog Maintenance Management  
Building and Structural Surveys  
Defect Diagnostics  
Party Wall Surveyor  
Planning and Building  
Regulation Applications  
Principal Designer  
RAAC Inspections, Assessments  
and Remedial Design  
Schedule of Condition and Dilapidations  
Spatial Planning and Feasibility Studies  
Topographical and Measured Surveys

### Project Management

Contract Administration  
Cost Planning and Control  
Design and Programme Management  
Project Briefing and Development  
Risk Analysis and Management  
Site Supervision  
and Quality Management  
Supply Chain Engagement

### Geotechnical and Geoenvironmental Engineering

Contaminated Land,  
Risk Assessments and Remediation  
Desktop Studies  
Earthworks Specifications  
and Site Supervision  
Geotechnical Engineering Design  
Materials Management  
Mining Investigations  
and Risk Assessments  
Site Investigations and Materials Testing  
Slope Stability Assessment  
and Embankment Design

### Specialist Services

Building Information Modelling (BIM)  
Conservation and Heritage  
Expert Witness and Dispute Services  
Maritime Civil Engineering  
Modern Methods of Construction (MMC)





[www.alanwood.co.uk](http://www.alanwood.co.uk)

- / Civil Engineering
- / Structural Engineering
- / Building Consultancy
- / Geotechnical and Geoenvironmental Engineering
- / Project Management
- / Specialist Services

#### **Locations:**

Hull  
Leeds  
Lincoln  
Scarborough  
Sheffield  
Stockton-on-Tees  
York