5.0 Recommended service and maintenance

Canopy and Ductwork

Internal clean to TR-19 specification, minimum once per year, monitored and possible increased to twice per year

Grease filters in the canopy should be removed and cleaned daily.

ESP module

Quarterly service, where the soiled cells are removed, and replaced with a clean cells. The casings should be cleaned to TR-19 standards.

The soiled cells are returned to the factory for steam cleaning.

MFU module, containing panel and carbon filters

The panel filters should be replaced quarterly

The carbon filters should be checked quarterly, and replaced at least annually.

Extract Air Fan

Quarterly check and a full service including a 'drawn current' test on the fan motor.